

CITROËN  SALOON

LIST OF SUBJECTS

DRIVING

Opening and locking	
Doors, boot, bonnet, windows	2
Driving position	
Controls and accessories	4
Instruments on panel	6
Driving position	
Seats, rear-view mirrors, seat belts	8
Starting	
Anti-theft device, ignition, starter, choke	10
Driving	
Gears, brakes, ground clearance	12
Signals and visibility	
Lamps, signals, windscreen wipers	14
Air-conditioning	
Ventilation, heating demisting	16
Accessories	
Ashtrays, sun-visors, interior lighting	18

MAINTENANCE

Water, oil and L.H.M. fluid levels	20
Mechanical and electrical	22
Bodywork	24
Interior	26

MINOR REPAIRS

Malfunction signalled by a dashboard warning lamp	6
Wheel replacement	28
Bulb replacement	30
Headlamp adjustment	34
Fuse replacement	35
Battery replacement	36
Sparking plug replacement	36
Replacement of L.H.M. fluid in an emergency	37
Starting using starting handle	37
Towing the car	38

TECHNICAL SPECIFICATIONS

General	40
Engine	42
Transmission	44
Hydraulic system	45
Suspension	46
Brakes	48
Steering and wheels	50
Electrical system	52
Bodywork and interior fittings	54

MISCELLANEOUS INFORMATION

Running-in, servicing, guarantee	56
Driving and running costs	56
Towing a trailer	57
Vehicle identification	57
Replacement parts	57
Travelling abroad	58

NOTE: positions are described as right-hand (R.H.) or left-hand (L.H.), as seen by a person standing behind the car and looking forward towards the bonnet.

—Descriptions of the various items fitted to the car, cover standard fittings and optional extras. The inclusion of a description does not therefore imply that the item described is fitted to all models.

Opening and locking	
Doors, boot, bonnet	2
Driving position	
Controls and accessories	4
Instruments on panel	6
Driving position	
Seats, rear-view mirrors, seat belts	8
Starting	
Anti-theft device, ignition, starter, choke	10
Driving	
Gears, brakes, ground clearance	12
Signals and visibility	
Lamps, signals, windscreen wipers	14
Air conditioning	
Ventilation, heating, de-misting	16
Accessories	
Ashtrays, sun-visors interior lighting	18

This first chapter contains all you need to know in order to drive your car, and take advantage of the comfort which it places at your disposal: the panel instruments are all described on page 6 so that you can find out the meaning of their signals with the minimum of effort, should the need arise.

We also advise you to read page 56 before taking the car on the road for the first time.



Fig. 1 - Keys
 1 - Anti-theft-ignition-starter
 2 - Side and rear doors
 3 - Glove compartment



Fig. 2 - Inside rear handle (according to model)
 1 - Opening
 2 - Locking

Keys (Fig. 1)

The largest key is for the combined "Anti-theft-Ignition" on the hydraulic gear-change version, or "Anti-theft-Ignition-Starter" on manual gear-change version (see page 10). One of the smaller keys locks the front side doors and the boot door (Mark 2). The other locks the glove compartment (Mark 3).

We recommend that note be taken of the numbers of these keys in the space provided in the "Maintenance Guide", which accompanies this handbook.

Side doors

From the outside:

To open : raise the handle.

To lock : use the key for the front doors. Before shutting each rear door, push the catch towards the front (Mark 2).

From the inside (Fig. 2) :

To open : move the catch towards the rear (Mark 1).

To lock : push the catch towards the front (Mark 2).

To unlock : return the catch to the middle position.

Opening the front doors operates the interior lighting.

Child safety locks

Lower the levers, situated under the locks on the rear side door edges : these doors can then only be opened from the outside.

Rear boot

To open : press the button, situated below the chevrons, and raise the lid which will remain in place automatically.

To close : lower the lid and press firmly.

The button may be locked using the front side door key.

Opening the boot operates the boot lighting.

Glove compartment

Turn the button clockwise to open. Opening operates the glove box lighting. The button may be locked with the key provided for this purpose.

Bonnet (Figs 3 and 4)

To open : Pull the two rings, situated on the L.H. and R.H. sides respectively of the interior, under the dashboard. The bonnet will open slightly. Slide your right hand under the bonnet, and raise the safety catch. To keep the bonnet open, use the support rod provided for this purpose.

To close: Release the support rod and lower the bonnet, keeping hold of it. Then let it fall freely for the last few inches. Make sure that the bonnet catch clicks home correctly.

Fuel filler :

This is situated under a cover, on the R.H. rear wing of the car. Raise the cover to gain access to the filler cap.



Fig. 3 - Opening the bonnet
1 - Unlocking ring



Fig. 4 - Opening the bonnet
1 - Safety catch



Fig. 5 - Gear lever (L.H.D.)
(on manual gear-change version)



Fig. 5 - Gear lever (R.H.D.)
(on manual gear-change version)

	See page
1 Defroster aperture/front L.H. window demister	16
2 L.H. ventilator	16
3 Gear selector (on hydraulic gear-change version)	12
Gear lever (on manual gear-change version)	
4 Ashtray	18
5 Stowage space	
6 Rear-view mirror	9
7 Loud-speaker (if fitted)	18
8 Control for sound-mixing between front and rear (if fitted)	18
9 Cigarette lighter	18
10 Glove compartment	2
11 R.H. ventilator	16
12 Defroster aperture/front R.H. window demister	16
13 Switch for direction indicators, headlamp flashers and horn	14
14 Windscreen wiper and washer switch	14
15 Control for directing air to the upper L.H. interior	16
16 Control for ventilation of upper L.H. interior	16
17 Control for ventilation of lower L.H. interior	16
18 Anti-theft/ignition control (on hydraulic gear-change version)	10
or anti-theft/ignition/starter control (on manual gear-change version)	
19 Switch for dashboard lighting rheostat	6
20 Auxiliary clutch control (on hydraulic gearchange version)	10
21 Switch for headlamps, side and tail lamps	15
22 Control for air distribution between upper and lower areas	16
23 Interior lighting switch	18
24 Air temperature adjustment control	17
25 Air blower switch	17
26 Air output adjustment control	16
27 Rear window heater switch	17
28 Switch for rear heating unit (for certain foreign countries)	
29 Control for ventilation of upper R.H. interior	16
30 Control for ventilation of lower R.H. interior	16
31 Control for directing air to the upper R.H. interior	16
32 Choke control	11
33 Fresh air blower switch (if fitted)	17





Fig. 6 - (L.H.D.)



- With the exception of the clock, the instruments function only when the ignition is on.
- The illumination of the dashboard instruments is controlled by the exterior lighting switch. It can be adjusted, as far as being completely extinguished by means of a button situated under the steering column, on the L.H. side (position 19, fig. 7) or R.H. side (position 19, fig. 5 [R.H.D.]).

1 Fuel gauge

Tank capacity: 65 l (14 imp. galls).

2 Check button for the red signals.

When depressed, the red signals, 8, 9, 10 and 17 should light up. This makes it possible to check, at any time, the working of these particularly important warning lamps. If they fail to light up, they should be overhauled without delay.

3 Speedometer.

With :

- Total mileage indicator.
- Trip mileage indicator (to return to zero, push and turn the button to the right of the speedometer — anticlockwise).
- Stopping distances (see page 13).

4 Water thermometer.

(For certain foreign countries).

5 Electronic tachometer.

The needle must not enter the red zone. Do not exceed 4000 r.p.m. during the first 600 miles (1 000 km).

6 Electric clock.

(If fitted).

Push and turn the button to adjust the time.

7 Blue warning lamp for headlamp main beam.

8 Red warning lamp for hydraulic pressure.

This can light up when the ignition is switched on and may remain lighted during the first few turns of the engine. Wait for it to go out before starting to move off. If it lights up during a journey, stop immediately, then drive slowly to the nearest Citroën Dealer using the parking brake.

9 Red warning lamp for engine oil pressure.

This will light up when the ignition is switched on and should go out as soon as the engine turns. If it lights up during a journey, stop the engine and check the oil level (see page 20). If it remains lighted despite the correct oil level, stop again and contact a Citroën Dealer.

10 Red warning lamp for water temperature.

If it lights up, stop the engine immediately, check the water level taking the

necessary precautions (see page 20) and top up if necessary. If it remains lighted despite the correct level, make your way slowly to a Citroën Dealer.

11 Green warning lamps for direction indicators.

If they do not function, check the corresponding indicators (see page 33).

13 Yellow warning lamp for front brakepad wear.

If this lights up when the pedal is depressed, the pads should be replaced as soon as possible (see page 13).

14 Yellow warning lamp for battery charge.



This will light up when the ignition is switched on and should go out as soon as the engine turns. If it lights up during a journey, contact the nearest Citroën Dealer having, however, checked the alternator and regulator connections. If the difficulty arises at night, avoid using the directional headlamps in order to conserve the current.

15 Yellow warning lamp for rear window heater.

16 Green warning lamp for sidelamps.

17 Red warning lamp indicating urgent need to stop.

Lights up with warning lamps 8,9 or 10.



This page left blank on purpose.

Fore-and-aft adjustment of the seats (Fig. 8 - Mark 1)

The locking lever for the seat is situated at the front, on the R.H. side. Move it vertically to adjust the seat. Release it to lock the seat in the desired position.

Back-rest inclination (Fig. 8 - Mark 2)

The grooved control knob is situated on the outside of the seat, at the base of the back-rest. Turn it to incline the back-rest or to set it upright again.

Reclined position : First put the seat in the foremost position, then incline the back-rest as far as it will go.

Height and angle adjuster (if fitted) (Fig. 8 - Marks 3 and 4)

When moved horizontally, the lever, situated at the front of the seat (middle part), makes it possible to adjust the front of the seat to any of three possible height positions.

When moved horizontally, the lever, situated at the rear of the seat, makes it possible to adjust the rear of the seat to any of three possible height positions.

Front height adjustment may be carried out whilst sitting in the seat.

Head-rest adjustment (if fitted)

The push buttons and the swivel facility of the rest, make it possible to adjust it to any of four different positions.



③



④

Fig. 8 - Seat adjustments

- 1 - Fore-and-aft-adjustments
- 2 - Back-rest inclination
- 3 - Front of seat-height adjuster (if fitted)
- 4 - Rear of seat-height adjuster (if fitted)

Rear-view mirrors

interior:

The lever, situated under the base of the rear-view mirror, enables it to be put into the "day" position: draw the lever towards the driver, or the "night" position: push the lever towards the windscreen.

exterior:

The stability of the mirrors and the lower part of the arm are adjustable by operating the screws provided for this purpose (Fig. 9 - Marks 1 and 2).

Seat belts (French market)

Our tests and world-wide statistics have proved the efficiency of the seat belts. The Société Citroën advises you to use them, while making sure that they are correctly adjusted.

To secure: Insert the end of the lever buckle into the flexible buckle of the same colour.

To release: Raise lever 1 (see Figure 10).

To adjust: The belt buckle must be level with the hips, at the side, and the strap should cross the chest. Alter the length of the short part (towards the centre of the car), by sliding the strap into the adjustment buckle; the belt should be adjusted so that it is not too tight on the body.

These belts are not designed for children under six years of age and any belt should only be used by one person at any given time.

The straps should not be twisted while in use. They should not be rubbed against the edges, since this may result in wear or breakage.

When a seat belt is not in use, hook the lever end, inserting it into the buckle situated under the upper anchorage point; to release it, move the opening lever.

If the belts have undergone any strain due to impact, replace them and have the anchorages checked.

For markets outside France, consult your Dealer who will advise you on legal requirements and fittings.

Driving position

Adjust the fore—and aft—position of the seat as well as its height and angle to suit the controls, then adjust the back-rest angle according to the driving style.

Adjust the rear-view mirrors to suit the driving position adopted.

Then fasten the seat belt and adjust its length if necessary.



Fig. 9 - Outside rear-view mirror
1-2 - Adjusting screws



Fig. 10 - Seat belt
1 - Opening



Fig. 11 - Starting
1 - Anti-theft device

Anti-theft device (Fig. 11 and 13)

This is situated in the lower part of the dashboard to the left of the steering column (or on the R.H. side on manual gear-change R.H.D. version). The successive positions of the key, turning clockwise, are as follows:

- 1 - Anti-theft (steering locked).
- 2 - Garage (steering free).
- 3 - Ignition on.
- 4 - Starter (only on manual gear-change version).

On hydraulic gear-change models, the starter is activated by the gear selector. Push it fully home, from neutral towards the left.

On the manual gear-change version:

- Release the key as soon as the engine has started.
- If the engine stops, or will not start at the first attempt, the ignition must be switched off before it is possible to operate the starter again (this is due to a safety device which prevents the starter motor from operating when the engine is running).

It may be necessary, in order to pass from the "anti-theft" position to the "garage" position, to slightly rock the steering wheel, while turning the key.

To withdraw the key, pull lightly when near the chosen position ("anti-theft" or "garage").

Never withdraw the key until the car has completely stopped.

Air filter intake control (if fitted)

This is situated on the L.H. side of the air filter and comprises two markings "summer" and "winter". See instructions for use on the opposite page (starting).

Choke control

Use only when the engine is cold.

See instructions for use on the opposite page (starting).

Auxiliary clutch control (on hydraulic gear-change version) (Fig. 12)

This control is designed to make it possible, during very cold weather or if the battery is low, to use the starting handle in order to start the engine or simply to free it (see page 37).

Having put on the parking brake and put the gear selector in neutral, press forward the lever of the auxiliary clutch control, then lock it by pushing it upwards. As soon as the engine starts, return the lever to its original position.

If the engine has only been freed by the starting handle, return the lever to its original position before operating the starter motor.



Fig. 12 - Starting with starting handle
(on hydraulic gear-change version)
1 - Auxiliary clutch lever

Before starting

Glance quickly at the list of checks found on the back of this manual, to avoid any oversights.

At the beginning of the cold season, place the air filter intake control (if fitted) in the "winter" position; likewise, at the beginning of the warm season, place it in the "summer" position.

Starting (do not run the engine in an enclosed space).

Do not touch the accelerator pedal.

Ensure that the gear lever is in neutral and that the parking brake is on.

Turn the key until the warning lamps for charging and engine oil pressure are illuminated. The ignition is on. The hydraulic pressure warning lamp may also light up.

If the engine is cold :

Pull the choke out fully (on hydraulic gear-change version: at the same time, press the "mushroom" main brake pedal). Operate the starter without touching the accelerator.

If the engine does not start the first time, wait three or four seconds before trying again (on manual gear-change version, also switch off the ignition).

If the engine is warm or hot:

Depress accelerator and operate the starter without touching the choke control.

If the engine does not start the first time, wait three or four seconds before trying again (on manual gear-change version, also switch off the ignition), without taking your foot off the accelerator.

Before engaging first gear

Push the choke back in so that the engine does not run in excess of between 900 and 1000 R.P.M.

Do not race the engine.

Allow the engine to run for a short time for the car to reach its normal running height.

The warning lamps for charging and engine oil pressure should have gone out.

If the hydraulic fluid pressure warning lamp is on, wait for it to go out.



Fig. 13 - Anti-theft device
1 - Anti-theft position
2 - Garage position
3 - Ignition
4 - Starter

Gear selection (Figs. 14, 14a and 15, according to model)

The gear positions are marked at the base of the selector on hydraulic gear-change version and on a diagram on the dashboard on manual gear-change version.

To engage reverse gear, wait until the vehicle is completely stationary.

On the hydraulic gear-change version, do not forget to put the selector in neutral when parking.

Fig. 14 - L.H.D.
5-speed diagram on
manual gear-change
version
AR - Reverse gear



Fig. 14 a - L.H.D.
4-speed diagram on
manual gear-change
version
AR - Reverse gear



Fig. 14 - R.H.D.
5-speed diagram on
manual gear-change
version
AR - Reverse gear




Fig. 15
4-speed diagram on
hydraulic gear-change
version
AR - Reverse gear
D - Starting





Fig. 14 a - R.H.D.
4-speed diagram on
manual gear-change
version
AR - Reverse gear



Adjustment of ground clearance (Fig. 16)

The control, situated to the left of the parking brake pedal bracket (or on the R.H. side of the drivers seat, on R.H.D. vehicles), gives 5 different car height settings.

The normal position, which assures greatest comfort, is obtained by selecting the second slot from the bottom.

The following two slots above are to be used on certain difficult roads.

The lowest slot gives the minimum height and the highest slot gives the maximum height.

These two positions, which are provided for wheel changing (see page 28) should not be used for normal running.

Exceptionally, however, it is possible to use the maximum height position with care and for a short distance, over particularly difficult surfaces.



Fig. 16 - Ground clearance adjustment
1 - Minimum height
2 - Normal running height
3-4 - Special heights
5 - Maximum height




Fig. 17 - Parking brake locking control (if fitted)
 A - Locking lever
 1 - Safety lock




Fig. 17 a - Parking brake lever (if fitted)
 1 - Movable grip
 2 - Catch handle
 3 - Safety lock

Emergency and parking brake

Footbrake (Fig. 17) (if fitted).

To lock the brake, put the locking lever (mark A) in the top position, then press the brake pedal (while all the other controls are extremely sensitive, the parking brake, however, requires to be strongly pressed).

To release, put the locking lever in the bottom position : the brake pedal will be freed automatically.

When running, the lever must always be in the bottom position.

A safety lock (mark 1), when it is pushed to the left, locks the locking lever in the upper position.

Handbrake (Fig. 17a) (if fitted).

To lock the brake, pull the movable grip (mark 1) until it catches automatically, staying in the locked position (while all the other controls are extremely sensitive, the parking brake, however, requires to be strongly pulled).

To release, pull the grip to release the catch: press the end of the lever (mark 2) with the thumb to slip the catch and push the grip right down, towards the front.

A safety lock may lock the catch handle: to do this, turn the milled screw through 90° (mark 3).

Starting on a hill on manual gear-change version

Declutch and engage first gear (or reverse gear).

Accelerate the engine slightly and begin to let in the clutch.

As soon as the vehicle begins to move, release the parking brake.

Main brake.

The main brake travel is very limited and the effort needed to operate it is very small, even for a sudden stop. It is a good idea, before taking your car onto the road for the first time, to practice operating the brake, so as to get the feel of its sensitivity and power.

Two warning lamps in the central warning cluster check the main brake :

The red warning lamp for hydraulic pressure is a signal requiring immediate stopping of the car then proceeding with care to a Citroën Dealer, using the parking brake.

The yellow warning lamp for front brake pads, which lights up when the brake is used, indicates that the brake pads need renewing. After changing the brake pads, the linings must be run in: immediate intensive use could lead to irregularities in braking.

Stopping distances

The exceptional comfort and road-holding qualities of the car allow the employment of full engine power and require particularly efficient brakes. However, whatever the system of braking, it remains essential to remember that at any moment, stopping distances increase considerably with the speed. For this reason we have inserted some of these on the speedometer. These are always based on the supposition that the tyres are in good condition, the car is not overloaded and of average road-adhesion as well as normal reflexes on the part of the driver.

These distances may be very much greater in other conditions, notably on wet or greasy ground.



Fig. 18 - Signal switches
 1 - R.H. indicators flasher
 2 - L.H. indicators flasher
 3 - Headlamp flasher
 4 - Horns



Fig 19 - 1 - Windscreen wipers
 2 - Windscreen washer

Control for direction indicators and horns (Fig. 18)

Direction indicators

Right-hand flasher and left-hand flasher: move the lever in the direction in which you are going to move the steering wheel. To cancel the signal, return the lever to the midway position.

The corresponding green warning lamp should flash in the warning cluster accompanied by an audible signal. If it does not work, check the direction indicators (see page 33).

Headlamp flasher

To flash headlamps: push the lever away from the steering wheel. The headlamps will remain on as long as the lever is pushed.

This control works when the lever is in any of the direction indicator positions.

Horns

Moving the lever towards the driver operates the first horn, by pulling further, the loud horn.

It is possible to operate the horns when the lever is in any of the direction indicator positions.

Switch for windscreen wipers and washer (Fig. 19)

Windscreen wipers

To operate: move the lever downwards: in the first position one obtains normal wiper speed, then, pushing further, an increased speed for exceptional use only, as in heavy rain or road spray from vehicles being overtaken.

To stop : push the lever upwards and the wipers will park automatically.

Windscreen washer:

Move the lever towards the steering wheel.

From time to time, clean the wiper blades (see page 24).

Headlamp control (Fig. 20)

- Off : the lights are off when the side of the knob, marked with a point, is in front of the driver.
- Side and tail : with the lever towards the steering wheel, turn the button one notch (a green warning lamp will light up in the warning cluster).
- Main beam : still with the lever towards the steering wheel, turn the button to the second notch (a blue lamp will light up).
- Dipped : From the "Main beam" or "Side and tail" position, pivot the lever away from the steering wheel.
- Directional lights: with the lever in the "Main beam" position, press the centre of the button: press again to extinguish.

Fig. 20 - Headlamp control
 1 - 'Side and tail' or 'Main beam' positions
 2 - Dipped position
 3 - Directional headlamps



Fig. 18 - R.H.D. Manual gear-change signalling
 1 - R.H. direction indicator
 2 - L.H. direction indicator
 3 - Headlamp flasher
 4 - Horns




Fig. 19 - R.H.D. Manual gear-change
 1 - Windscreen wipers
 2 - Windscreen washer



Fig. 20 - R.H.D. Manual gear-change - headlamp control
 1 - 'Side and tail' or 'Main beam' positions
 2 - Dipped position
 3 - Directional headlamps



Fig. 22 - Side ventilators control
 1 - Ventilation of upper interior
 2 - Direction of ventilation of upper interior
 3 - Ventilation of lower interior

Side ventilators (cold air only) (see Fig. 22)

High level ventilation

To operate : move the upper lever (mark 1) to the left, more or less according to the required output.

To stop : push home to the right.

To orientate: raise or lower the outer lever (mark 2) to direct the air upwards or to the front passengers face.

Low level ventilation

To operate : move the lower lever (mark 3) to the left, more or less according to the required output.

To stop : push home to the right.

Air ducts for the windscreen, front windows and floor (hot or cold air) (Fig. 23 - Mark 1)

To operate : move the lever to the left, more or less according to the required output.

To stop : push home to the right.

Air distribution between upper and lower areas (hot or cold air) (Fig. 23 - Mark 2)

Fully to the left : air is directed towards the floor.

Fully to the right : air is directed towards the windscreen and front windows.

Intermediate positions: air is divided between the upper and lower areas.




Fig. 23 - Air conditioning controls (L.H.D.)
 1 - Air flow
 2 - Air distribution between windscreen and floor
 3 - Forced air control
 4 - Temperature adjustment

Adjustment of air temperature (Fig. 23 - Mark 4)

To operate : move the lever towards the left, selecting the desired temperature.

To stop : push home to the right.

Air blower (Fig. 23)

To operate : press the switch.

To stop : press again.

The air blower (Mark 3) makes it possible, when stationary or travelling slowly, to obtain fresh air from the L.H. side ventilator and fresh or warm air from the air ducts for the windscreen, front windows and floor.

The blower (Mark 5) (if fitted) makes it possible, in the same conditions, to obtain fresh air from the R.H. side ventilator and from the R.H. side floor outlet.

Electric heating for rear-window (Fig. 24)

To operate : press the switch. The corresponding yellow warning lamp lights up on the dashboard.

To stop : press again.

The heating for the rear-window works only when the ignition is on.




Fig. 23 - Air-conditioning controls (R.H.D.)

- 1 - Air flow
- 2 - Air distribution between windscreen and floor
- 3 - Forced air control
- 4 - Temperature adjustment
- 5 - Fresh air blower control (if fitted)



Fig. 24 - Electric heating for rear-window

Ashtrays

To remove them, pull out as far as possible and press the spring strip. The front ashtray is illuminated when the headlamps are being used (according to model). The intensity of the light can be regulated by using the lighting rheostat switch which is located on the dashboard (see page 6).

Cigarette lighter

Press in and wait until it returns to its original position before removing. It is illuminated (if fitted) when the headlamps are on.

Sun visors

These are adjustable and may be turned to the side. The sun visor for the passenger is fitted with a mirror.

Radio set (if fitted)

The location for the radio set is provided on the engine recess. A control for sound mixing between front and rear, provided on the dashboard (at the side of the loudspeaker), makes for listening under the best acoustic conditions.

Illumination of ignition key housing (if fitted)

This housing is lit up when the headlamps are being used. The intensity of the light can be regulated by using the lighting rheostat switch which is located on the dashboard (see page 6).

Illumination of glove compartment (if fitted)

This lights up automatically when the lid is opened.

Illumination of heating control (if fitted)

This lights up when the headlamps are being used.

Interior lamps

These light up automatically when the front doors are opened. They also come on when the switch is pressed (Fig. 25).



Fig. 25 - Interior lighting switch

MAINTENANCE

Water, oil, L.H.M. fluid levels	20
Mechanical and electrical	23
Bodywork	24
Interior	26


This chapter deals with the small points which are essential to ensure the good condition of your car : checking levels, keeping an eye on the tyres, washing the bodywork...

Other maintenance operations, such as greasing, oil changes, adjustments... which the Citroën network will competently carry out for you, through its special service stations, form the subject of the "Maintenance Guide" which has been supplied with this manual.



Fig. 26 - Hydraulic reservoir
1 - Level checking sight-tube

1. **Radiator filler cap on "DS 23"**
Radiator on "D Super 5" - "DS 20" - "D Super" - "D Special".
 Turn the cap as far as the safety notch, then apply pressure to continue.
 If the engine is hot, stop at the notch and let the steam escape before continuing turning.
 The level should be 2 - 3 cm (4/5"-1 1/5") from the lower flange of the filler opening.
 Do not top up the radiator of a warm engine with more than 1/2 l (7/8 imp pints) of cold water. Wait for it to cool down before continuing.
2. **Windscreen washer**
 Fill up with clean water to which may be added a tablet of "Stop Clair" or a similar product during any season, or "Stop Gel" or a similar product during winter.
3. **Dipstick**
 The level, which should be between the two ends of the cut out, should be checked between oil changes, particularly before any long journey.
 The check should be carried out with the car horizontal and the engine should have been stopped for at least 10 minutes.
 To complete, fill up without the level being higher than the top end of the dipstick cut out. The length of the cut out is the equivalent of 1 l (1 3/4 pints).
4. **Engine oil filler pipe**
 In winter, as in summer, use "TOTAL Altigrade GT Special Autoroute 20 W 40" or "GTS 20 W 50" oil or equivalent oils of other reputable makes. In very cold countries (ie. where the temperature is frequently lower than -10°C (14°F)) use "TOTAL Altigrade GT Special Autoroute 10 W 30" or "GTS 10 W 30" oil, or equivalent oils of other reputable makes. Never use additives.
5. **Battery**
 Check the level from time to time, especially in summer.
 It should be between 1 and 2 cm (2/5" and 4/5") above the plates in each of the six cells. Top up with distilled water. Never add acid.
 Never bring any flame near the battery during a check.
6. **Hydraulic reservoir.**
 The level, which can be seen through the sight tube (see Figure 26) must be between the "Min." and "Max." marks. The check should be carried out with the vehicle in the maximum height position (see page 12).
Important: To top up, use exclusively green "LHM" fluid.
All other fluids, particularly those of vegetable or synthetic origin, which would rapidly destroy the hydraulic installation, are not to be used.
We recommend to you green "LHM" fluid distributed by TOTAL.
 In an emergency, or if it is not possible to obtain green "LHM" fluid, see page 37.






Fig. 28 - Tyre wear indicators
1 - Warning areas

Periodic maintenance operations

These are indicated in the "Maintenance Guide" which accompanies this manual. We would recommend you to adhere to the frequencies indicated and would remind you that we recommend "TOTAL" lubricants. All mixtures and experiments are forbidden, and, in particular, the use of oil additives of any kind, as these may lead to serious trouble.

Tyres*

French market: Michelin tyres.

Series fitted	"DS 23" - "D Super 5"	"DS 20" - "D Super" - "D Sp."	Pressures	
			Bars	P.S.I.
Front wheels	180 HR 15 X AS	180 HR - 15 X AS	2	29
Rear wheels	165 HR 15 X AS	155 HR - 15 X AS	2	29
Spare wheel	165 HR 15 X AS	155 HR - 15 X AS	2.2	32

If a front tyre is punctured, the spare wheel may be used as a provisional replacement until the next repair station is reached

Other markets: Michelin tyres.

Series fitted	All models	Pressures	
		Bars	P.S.I.
Front wheels	180 HR 15 X AS	2	29
Rear wheels		1.8	26
Spare wheel		2.2	32

Authorised alternatives (on front and rear wheels): 180/15 XH - 185/15 X (M+S) - 185/15 X.

Inflation pressures: front - 2 bars (29 P.S.I.)
 rear - 1.8 bars (26 P.S.I.)
 spare - 2.2 bars (32 P.S.I.)

When "180/15 XH", "180/15 X (M+S)" and "185/15 X" are fitted, you are advised not to exceed 100 MPH (165 km/h). These pressures are appropriate whether the vehicle is empty or fully laden, on ordinary roads or motorways, whatever the speed. Do not forget to adjust the spare wheel pressure as soon as possible after putting it in use.

It is necessary to check the pressures at least once every month and before any long journey, because safety depends on this. It is also a great influence on the life of the tyres. The checks should be carried out cold before the tyres have been heated by running. The pressure may in fact be increased by up to 0.5 bar (7 P.S.I.) on a loaded vehicle running at high speed.

Check the wheels for balance especially after a puncture repair.

"X AS" tyres have on one side wall, the inscription "outside". It is essential that the tyre should, after repairs, be re-fitted on the wheel accordingly.

Changing the wheels round evens out the wear on the five tyres. Thus, the wheels should be changed round sufficiently often to avoid any appreciable difference in wear between the two tyres on any one axle.

Follow the diagram (Fig. 28 a) with which brings the spare wheel into the sequence. Adjust the pressures after each change.

The instructions for changing a wheel are shown on page 28.

Wear indicators

They are located at regular intervals across the tread and show up according to localised wear of the engraving, when the rubber reaches a certain degree of wear (see Fig. 28). The tyre concerned should then be replaced as soon as possible.

Snow tyres

The tyres "180-15 XH" and "180-15 X (M+S)" may be fitted with spikes but it is then necessary to increase the pressures by 0.2 bars (3 P.S.I.).

The use of tyres with spikes is subject to specific conditions. Contact your Citroën Dealer who will give you all the relevant information.

Battery maintenance

Check the terminals and leads for cleanliness. If they are sulphated, unscrew them, clean them and soak the felt insulating washers in castor oil or in neutral vaseline oil. If the car is not in use, recharge the battery every month.

In winter, a correct charge prevents freezing: a battery normally charged (a density of 1.25 to 1.27) resists to -50°C (-58°F) whilst a discharged battery (density 1.07 - 1.09 may burst at -5°C (23°F)).

Do not disconnect the leads from the battery terminals when the engine is running.

Never recharge the battery without having disconnected the leads from the two terminals.

Radiator maintenance

The cooling water contains, when it leaves the factory, a dose of anti-freeze sufficient to protect the radiator and the cylinder block down to the temperature indicated on the label stuck to the radiator filler cap, with the capacity of the radiator being:

- 13 l (23 imp pints) on "DS 23", the proportion needed to protect the engine down to -15°C (-5°F) is 6 l (10.5 imp pints) of anti-freeze, and 7 l (12.5 imp pints) water.
- 10.8 l (19 imp pints) on "D Super 5", this proportion is 3.8 l (7 imp pints) anti-freeze and 7 l (12 imp pints) water.
- 10.6 l (18 imp pints) on "DS 20", "D Super" and "D Special": this proportion is 3.6 l (6.5 imp pints) anti-freeze and 7 l (12.5 imp pints) water.

"TOTAL" anti-freeze contains a corrosion inhibitor.

We recommend renewing the cooling fluid once per year, at the beginning of the cold season. This is a delicate operation and should be carried out by a Citroën Dealer.

Cleaning

An opening, operated by a zip fastener, makes it possible to clean, if necessary, the front face of the radiator (see Fig. 29). Under normal conditions, this should always be closed.

Under conditions of very dense snow and under exceptional circumstances, keep the flap open by means of the press stud provided for this purpose.




Fig. 28a - Tyre change-round



Fig. 29 - Cleaning the radiator
1 - Zip fastener
2 - Press stud

The bodywork should be looked after regularly, especially in winter. This maintenance should not only concentrate on the paintwork and the metal decorative components but should take in the underside of the car as well: advice in this connection can be obtained from any Citroën Dealer.

Never wipe the car when dry, since this will scratch the paintwork finish.

Petrol, trichlorethylene and alcohol harm paint and transparent plastic, such as the sidelamp covers. Do not use strong detergent solutions either.

Cleaning the bodywork

Frequent washing is necessary to keep the paintwork in good condition but it is nevertheless essential that certain precautions be observed; here are some reminders:

Never wash the car in full sunlight nor during frost. If the car has been heated by the sun or the bonnet is still warm after a journey, wait until the surfaces have cooled down.

The body should first be rinsed with copious amounts of water, applied either with a soft sponge, using no pressure and rinsing the sponge often, or with a low pressure jet. If a car shampoo is used, rinse afterwards with plenty of water.

Wipe the car dry with a clean chamois leather which is rinsed and wrung out frequently; ensure that no spots of water are left on the paintwork.

When setting off, apply the brakes a few times to dry out any water from the brake linings.

Cleaning the windows

The windows can be cleaned with alcohol or special glass cleaners, except the inside of the rear-window, if equipped with electric heating (see page 26).

We advise against products with a silicone base.

Hinge the windscreen wiper blades forward and clean them with soapy water, without exerting pressure on the rubber edge.

Metal decorative components

Wash in suds or water, to which a little detergent such as Teepol has been added (2.5 to 3.0 cu. in. per gallon or 10 to 15 cm³ per litre), preceded and followed by copious amounts of clean water.

The wheel embellishers in particular should be washed very often, since in time, mud might damage the surface so that repolishing may become necessary.

After drying with a leather, it is recommended that a product like "ABEL Polish-chrome" or other proprietary chrome-polishes, be applied as a protection for the polished metal finish.

Spots of tar on the bodywork

These should be removed as soon as possible.

Do not scrape off and do not use petroi or a spot remover for cloth, but a special tar remover, such as "ABEL".

Polishing the paintwork

Polishing is not recommended for metallic paintwork because of the risk of rings appearing.

On the other hand, for non-metallic paintwork, it is recommended to carry out polishing at the end of winter; for this, the body must be perfectly clean and dry.

Use products that are only slightly abrasive, i.e. liquid polishes (e.g. "LAVABEL") and follow the manufacturer's instructions.

Paint reference

The paint reference for the car can be found on a small disc (Fig. 30 a), under the bonnet, attached to the bulkhead, near the R.H. air duct.



Fig. 30 a - Paint reference disc for the car

Cleaning the upholstery

Only use non-caustic soaps, toilet type.

Fabric upholstery :

These may be brushed or, preferably, suction cleaned. If there is much general dirt, use commercial "dry foam"; after carefully removing all traces of dust.

Leather upholstery :

This should be cleaned with a cloth or sponge dipped in tepid soapy water, well rinsed, and then rubbed with a soft cloth until it shines. Do not use cream, which may stain.

Imitation leather upholstery :

Clean with a product of the "Spic" type or with a little soapy water. Rinse well then rub with a dry cloth. We do not advise products sold to make these parts shine.

Isolated marks on the upholstery

Marks on the fabric, leather, or imitation leather, may be cleaned with soapy water or water with a little 'Teepol' detergent added.

If these do not remove them, use 90° alcohol (commercial methylated spirit), or lead-free petrol.

Use squeezed out pads and rub the marks lightly.

Solvents such as acetone, trichlorethylene etc, are not recommended.

There are complex cleaners containing absorbent materials which, used with care, have the advantage of not leaving rings. (e.g. "K2R").

Seat belts

These should be cleaned with soapy water, or with water with a little detergent of the "Teepol" type added, taking care not to touch the metal parts. Remove the deepest stains with 90° alcohol (commercial methylated spirit) or with lead-free petrol.

Do not dye the belts, as this may lower their capacity for resistance.

Dials on instrument panel

Use either soapy water or a commercial diluent, to the exclusion of all other products.

Steering wheel

Use soapy water or a detergent additive such as 'Teepol'. Under no circumstances use solvents such as alcohol, lead-free petrol or trichlorethylene.

Heated rear-window

The interior of the rear-window should only be cleaned with soapy water, to avoid damaging the printed circuit for the electric heating.

MINOR REPAIRS

Replacing a wheel	28
Replacing a bulb	30
Adjusting the headlamps	34
Replacing a fuse	35
Replacing the battery	36
Replacing a sparking plug	36
Replacing 'LHM' fluid in an emergency	37
Using starting handle to start engine	37
Towing	38

You should consult this chapter should any difficulties, such as a puncture or a sparking plug which needs changing, arise. If, however, the difficulty takes the form of a dashboard instrument warning lamp, you should consult page 6 of the manual.



Fig. 31 - Tools for removing wheels
 1 - Joint starting handle and wheel brace
 2 - Stay
 3 - Peg



Fig. 32 - Removal of a rear wing



Fig. 33 - Removing a large wheel embellisher



Fig. 33 a - Removing a small wheel embellisher

Toolkit (Fig. 31)

It is stored under the bonnet: the stay held by the peg in the centre of the sparewheel. The starting handle and wheel brace under the spare wheel.

Removal

Apply the parking brake fully.

Start the engine and let it run at idling speed.

Place the manual height control lever in the highest notch (maximum height).

Rear wheels only:

Remove the wing by unscrewing the rear fixing screw, using the wheel brace (see Fig. 32), then draw the wing towards the rear, raising it slightly.

Remove the embellisher following this plan, according to the appropriate model:

Large embellishers: Insert the curved end of the jacking peg into the hole for the valve to serve as a lever (see Fig. 33).

Small embellishers: Slide it by pressing it in line with the valve. Remove it by sliding the curved end of the jacking peg between it and the wheel and by levering (see Fig. 33 a).

Slacken, without removing, the five wheel nuts with the brace. This loosening is facilitated by using the extension.

When the vehicle is at maximum height, engage the jacking stay in the lug under the front door and engage the straight end of the jacking peg into the hole nearest the notch situated in the upper part of the base (see Fig. 34).

Place the manual height control lever in the lowest position and remove the wheel.

Refitting

Place the end of the wheel-brace extension into the centre hole of the wheel to be refitted and engage it in the central hole of the hub (Fig. 35).

Hold the extension, raising it, and slide the wheel to engage it on the studs.

Screw on the 5 nuts without tightening them.

Place the manual height control lever in the highest notch (maximum height).

Disengage the stay.

Tightly lock the 5 nuts using the wheel-brace without the extension. Replace the wheel embellishers (according to model) :

Large embellishers : Paying attention to the position of the hole for the valve (see Fig. 36).

Small embellishers : First engaging the leafspring in one of the holes and pushing on the other end to engage it in the second securing hole (see Fig. 36 a).

Rear wheels only :

Refit the wing, engaging, first of all, the holding lugs into their respective housings.

Push it home towards the front and then refit the rear securing screw (Fig. 32).

Place the manual height control lever in its original position.

Check as soon as possible the pressure of the tyre of the wheel just fitted (see the data summary on the back of this handbook).



Fig. 34 - Positioning the jacking stay



Headlamps


They comprise :

- Outer : Dipped/Main beam headlamps (large diameter) with sidelamps incorporated.
- Inner : Long-range headlamps (small diameter), fixed or directional.

They are fitted with either "European-Dip type" bulbs or "Quartz-Iodine" bulbs, according to model.

A hole in the wings gives access to the rear part of the headlamp units and thus makes the replacement of bulbs possible. Do not undertake the replacement operation unless the lamps have been switched off for at least 5 minutes.

Take care not to touch the new bulb with the fingers. If this is done inadvertently, take another bulb or clean that which has been touched, with a little soapy water and dry with a non-fluffy cloth.



Dipped/Main beam headlamps (large diameter) European-Dip type bulbs (if fitted).
 (12 V - 45/40 W - Type P 45 - T 41)

"Marchal" component (metal bulb-holder) (Fig. 37).

- Remove the bulb holder by pulling it.
- Disconnect the connector by pulling it (Mark 1).
- Press on the retaining springs (Mark 2) to disengage them.
- Lift out the cover and change the bulb.

"Cibié" component (bulb-holder in black plastic) (Fig. 38).

- Turn the unit in the direction of the arrow marked "demontage" (clockwise), then pull to remove.
- Change the bulb then replace the unit by turning it in the direction of the arrow marked "montage" (anti-clockwise).

Fig. 37 - Main beam/Dipped (large diameter)
 Marchal European-Dip type bulbs (if fitted)
 1 - Connector
 2 - Retaining springs
 3 - Sidelamp (see page 33)



Fig. 38 - Main beam/Dipped (large diameter)
 Cibié European-Dip type bulbs (if fitted)
 1 - Sidelamp (see page 33)




Fig. 39 - Main beam/Dipped (large diameter)
Marchal H 4 Quartz Iodine bulbs (if fitted)
1 - Bulb holder assembly
2 - Bulb
3 - Connector
4 - Coil spring
5 - Securing lugs
6 - Sidelamp (see page 33)

Dipped/Main beam headlamps (large diameter) with Quartz Iodine bulbs, H 4 type.
(12 V - 50/60 W - H 4 type) (if fitted).

"Marchal" component (Fig. 39).

- Push white plastic assembly (Mark 1) and turn it : it will separate automatically from the reflector.
- Disconnect the faulty bulb (Mark 2) from the connector (Mark 3) by pulling it.
- Insert a new bulb into the coil spring (Mark 4) of the assembly.
- Refit connector to the terminal of the bulb (3 contact pins).
- Refit the assembly in the reflector, taking care to insert the three securing lugs of the flange (Mark 5) into the corresponding notches (red mark upwards).
- Push the assembly and turn it until it locks.




Fig. 40 - Main beam/Dipped (large diameter)
Cibié H 4 Quartz Iodine bulbs (if fitted)
1 - Bulb holder assembly
2 - Bulb
3 - Bulb base (3 leads)
4 - Sidelamp (see page 33)

"Cibié" component (Fig. 40).

- Turn the black plastic assembly (Mark 1) following the arrow marked "demon- tage" then pull to disengage it from reflector.
- Disconnect the faulty bulb (Mark 2) by pulling it.
- Reconnect a new bulb, taking care to position the three base arrows correctly (Mark 3).
- Replace the unit in the reflector (use the 'upward' mark) and turn it in the direction of the arrow marked "montage".

Main Beam/Dipped headlamps (large diameter) with Quartz Iodine H 1 bulbs.

(12 V - 55/60 W - H 1 type) (if fitted).

Dipped headlamps : upper bulb.

Main beam headlamps : lower bulb.

A. "Marchal" component (Fig. 39 a).

Turn the rim (Mark 1) and the bulb holder assembly (Mark 2) will separate automatically.

Pull the faulty bulb to separate it from the connector (Mark 3).

Insert a new bulb, taking care over the positioning of the cut-off part of the bulb flange.

Reposition the bulb holder assembly. Take care to catch the rim teeth.

B. "Cibié" component (Fig. 40 a).

Press the stop (Mark 1) and the bulb holder assembly will separate automatically.

Disconnect the assembly and separate the lead from the bulb base.

Insert a new bulb, taking care over the positioning of the cut-off part of the bulb flange.




Fig. 39 a - Main beam/Dipped (large diameter) Marchal H 1 Quartz Iodine bulbs (if fitted)
 1 - Rim
 2 - Bulb holder assembly
 3 - Bulb and connector
 4 - Sidelamp (see page 33)



Fig. 40 a - Main beam/Dipped (large diameter) Cibié H 1 Quartz Iodine bulbs (if fitted)
 1 - Release stop
 2 - Sidelamp (see page 33)




Fig. 41 - Long-range headlamps
(small diameter)
European-Dip type bulbs (if fitted)
1 - Retaining springs
2 - Connector

Long-range headlamps (small diameter) with Quartz Iodine bulbs (Fig. 41)
(if fitted) (12 V - 45/40 W - P 45 - T 41 type).

Disconnect the black plastic connector (Mark 2), by pulling it.

Disengage the retaining springs (Mark 1).

Replace the bulb.

When putting the assembly back in position, take care over the positioning of the lug.




Fig. 42 - Long-range headlamps
(small diameter)
Quartz Iodine bulbs (if fitted)
1 - Retaining spring

Long-range headlamps (small diameter) with Quartz-Iodine bulbs (Fig. 42).
(If fitted) (12 V - 55/60 W H 1 type).

Unhook the retaining spring (Mark 1).

Disconnect the lead from the bulb terminal.

Replace the bulb.

Take care over the positioning of the lugs when replacing the assembly.

Sidelamps

- Front (12 V - 4 W - T 8/4 type)
These bulbs are integrated in the Dipped/Main beam headlamps (large diameter) (see Figs 37 to 40).
Pull the holder, turning it slightly.
- Rear (12 V - 5 W - R 19/5 type)
Remove the transparent cover (2 screws to slacken).

Direction indicators. (12 V - 21 W - P 25/1 type)

- Front (Fig. 43).
Remove the cover (2 screws to slacken).
Disengage the bulb holder, swinging the holding connecting strip.
- Rear (Fig. 44).
Disengage the lamp from the cover by pulling its lower lug.
Replace it, first of all engaging the upper lug then the lower one.

Brake lamps (12 V - 21 W - P 25/1 type)

Disengage the transparent cover (two screws to slacken).

Reversing lamps (if fitted) (12 V - 21 W - P 25/1 type)

Disengage the glass cover (two screws to slacken).

Number plate lamp (12 V - 5 W - R 19/5 type)

Disengage the transparent cover (two connecting screws).

Interior lighting (Festoon 12 V - 7 W - length 38 mm)

"Pallas" interior lighting (bayonet - 12 V - 15 W)

Glove compartment (if fitted) (12 V - 2 W T 8/2 type)

Lift out the white cover, pulling it downwards and slightly towards the side to disengage it.

Rear boot (Festoon - 12 V - 7 W - length 38 mm)

The bulb is located on the left hand side, on a level with the upper shelf.
Remove the cover, pulling it downwards.

Control panel

Dashboard lighting (12 V - 2 W - wedge type - base of tube $\varnothing = 10$ mm)
Warning lamps (BA - 9 S - 12 V - 2 W - T 8/2 type)

Heater control (if fitted) (BA - 9 S - 12 V - 2 W - T 8/2 type)

Clock lamp (if fitted) (BA - 9 S - 12 V - 2 W - T 8/2 type)

Ashtray lamp (if fitted) (BA - 9 S - 12 V - 2 W - T 8/2 type)

Cigarette lighter lamp (if fitted) (BA - 9 S - 12 V - 2 W - T 8/2 type)



Fig. 43 - Front direction Indicators



Fig. 44 - Rear direction indicators




Fig. 45 - Dipped/Main beam headlamps (large \varnothing)
Self-levelling
1 - Vertical adjustment
2 - Horizontal adjustment




Fig. 45 a - Dipped/Main beam headlamps (large \varnothing)
fixed
1 - Vertical adjustment
2 - Horizontal adjustment



Fig. 46 - Long-range headlamps (small \varnothing)
directional
1 - Vertical adjuster




Fig. 46 a - Long-range headlamps (small \varnothing)
directional
2 - Adjusting sleeve
3 - Lock-nut

These adjustments can only be carried out effectively in a workshop equipped with the necessary checking devices.

- Dipped/Main beam headlamps (large diameter).
- Self-levelling (Fig. 45).

Vertical adjustment : turn the screw (Mark 1).

Horizontal adjustment : turn the screw (Mark 2).

- Fixed headlamps (Fig. 45 a).

Vertical adjustment : turn the screw (Mark 1).

Horizontal adjustment : turn the screw (Mark 2).

- Long-range headlamps (small diameter)

- Directional (Figs. 46 and 46 a).

Vertical adjustment : turn the knurled knob (Mark 1)

Horizontal adjustment : turn the white sleeve (Mark 2) after first loosening the lock nut (Mark 3).

Towards the right : adjusts the beam towards the right.

Towards the left : adjusts the beam towards the left.

After carrying out the adjustment, do not forget to lock the lock nut.

- Fixed headlamps (Fig. 46 b).

Vertical adjustment : turn the screw (Mark 1).

Horizontal adjustment : turn the screw (Mark 2).




Fig. 46 b - Long-range headlamps (small \varnothing)
fixed
1 - Vertical adjustment
2 - Horizontal adjustment

It is necessary, before replacing a blown fuse, to determine the cause and have this remedied.

The 10 fuses protecting the circuit (3 fuses of 16 amps and 7 of 10 amps) are found under the bonnet and are distributed in the following way:

- Left hand side : One box, and an in-line fuse on the L.H. wing wiring harness.
- Right hand side : One box, and an in-line fuse on the R.H. wing wiring harness.

Remove the cover of the box by pulling it and replace the fuse with another of the same amperage.

List of fuses and equipment protected :

Left-hand side :

1. Mauve marking (10 a)

L.H. dipped headlamp

3. Green marking (16 a)

Interior and boot lighting
Warning lamps and direction indicators
Cigarette lighter
Rear-window heating
Reversing lamps
Air blower
Battery charging circuit

5. Yellow marking (16 a)

Front and rear R.H. side-lamps
Number-plate lighting
Cigarette lighter, ashtray, heater control, clock and dashboard lighting
Side and tail-lamp warning light

2. Red marking (16 a)

Electronic tachometer
Rheostat and fuel gauge
Warning lamp cluster
Windscreen washer pump and wiper motor
Accessory terminal
Brake lamps
Heating and fresh air blower
Clock
Glove compartment lighting

4. White marking (10 a)

R.H. dipped headlamp

6. Blue marking (10 a)

Front and rear L.H. side-lamps

7. Mauve marking (10 a) (in-line fuse)

L.H. Long-range headlamps

9. White marking (10 a)

R.H. main beam headlamp

Right-hand side :

8. Mauve marking (10 a) (in-line fuse)

Long-range R.H. headlamps

10. Yellow marking (10 a)

L.H. main beam headlamp




Fig. 47 - L.H. side fuses



Fig. 47 a - R.H. side fuses



Fig. 48 - Electrode gap

Battery replacement

Battery references : 12 V - 200/40 , 250/50 or 300/60 AH CEI (according to model)

Disconnect the battery terminals, always starting with the negative terminal.

Disconnect the starter motor relay from the positive terminal (on hydraulic gear-change version).

Disconnect the speedometer cable relay.

Unscrew the two frame tie-rods of the battery, and disconnect the relay leads marking their position, then pivot the frame towards the front.

Raise the battery.

Ensure correct positioning of the terminals before putting the battery back in place.

Sparking plug replacement

Original fitting : AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S - Marchal 35.1.B

Other authorized alternatives :

on "DS 23" and "D Super 5"	on "DS 20", "D Super" and "D Special"
Beru 240-14 Champion L 87 Y Marelli CW 7 N Hitachi M 43	Champion L 87 Y Marelli CW 7 N

Sparking plug gap : 0.6 to 0.7 mm (0.024" to 0.028").

To refit a sparking plug :

- push a rubber tube over the insulator of the replacement plug
- screw it in by hand as far as possible
- finish tightening with the spanner.

To remove sparking plug for N° 4 cylinder :

- remove the rubber plug from the scuttle gutter
- insert the plug spanner into the hole now apparent.

Replacement of the green "LHM" fluid in an emergency

In an emergency, it is possible to use an SAE 10 or SAE 20 engine oil in place of the green "LHM" fluid or also a "A Suffix A" or "Dexron" type automatic gearbox oil.

However, as soon as possible afterwards, the reservoir must be drained by a Citroën Dealer who should then top it up again with the green "LHM" fluid.

Using the starting handle to start the engine (on the hydraulic gear-change version and vehicles fitted with a 4-speed gearbox only).

The starting handle is situated under the spare wheel, inserted on its extension (see Fig. 31 - page 28). In order to use it, remove the plug which seals the eye located under the front bumper, behind the number-plate.

Do not forget to keep the parking brake on and make sure that the gear selection lever is in neutral. See auxiliary clutch control on page 10.

Towing the car

From the front : attach a cable to the lower left and right-hand wheel arms and protect the lower part of the closing panel, by inserting a piece of wood and stout padding.

Then raise the vehicle.

From the rear : attach a cable to the right and left suspension arms, taking all the precautions necessary for the protection of the closing panels of the body.

While the car is being towed with the engine stopped, the driver must use only the parking brake, since the high pressure pump supply is inoperative.

Door locks frozen up

Maintenance :

At the beginning of the cold season, insert into the door-locks a small amount of glycerin or anti-freeze, using an oiler or a dropper.

In case of emergency :

Heat the key slightly with a match flame or a lighter before inserting it.

TECHNICAL SPECIFICATIONS

General	42
Engine	42
Transmission	44
Hydraulic system	45
Suspension	46
Braking	48
Steering and wheels	50
Electrical system	52
Bodywork and interior fittings ..	54

The section will enable you, if you so desire, to learn more about your car.

Saloon - Front wheel drive

Number of seats : 5.

Fiscal rating : "DS 23" : 13 CV

"D Super 5" : 12 CV

"DS 20", "D Super" and "D Special" : 11 CV

Top speed : "DS 23" : 178 km/h (111 m.p.h.) (hydraulic gear-change) : 179 km/h (112 m.p.h.) (manual gear-change)

"D Super 5" : approx. 176 km/h (110 m.p.h.)

"DS 20", "D Super" and "D Special" : approx. 169 km/h (106 m.p.h.)

Maximum slope for starting with a towing load of 1800 kg (3968 lbs) : "DS 23" - "D Super 5" - 11.5 % (1 in 8.7)

"DS 20" - "D Super" - 11 % (1 in 9)

Speed at 1 000 r.p.m.	hyd. "DS 23" manual		"D Super 5"		"DS 20"		"D Super" / "D Special"					
	km/h	m.p.h.	km/h	m.p.h.	km/h	m.p.h.	km/h	m.p.h.				
First gear	8.7	5.4	8.7	5.4	8.7	5.4	8.7	5.4	7.9	5		
Second gear	15.5	9.7	14.6	9.1	14.6	9.1	15.5	9.7	13.9	8.6		
Third gear	23.5	14.7	21.5	13.4	21.5	13.4	23.5	14.7	22.6	14.1		
Fourth gear	33.3	20.8	29.3	18.3	29.3	18.3	33.3	20.8	32.5	20.4		
Fifth gear	—	—	36.2	22.6	36.2	22.6	—	—	—	—		
Reverse	9.0	5.6	9.0	5.6	9.0	5.6	9.0	5.6	8.1	5.6		
Final drive ratio	8/35 (4.375 : 1)				8/35 (4.375 : 1)		8/35 (4.375 : 1)		7/34 (4.857 : 1)			
Weights	kg		lbs		kg		lbs		kg		lbs	
*Unladen, in running order	1 320		3 110		1 310		2 888		1 300		2 888	
- on front wheels	880		1 940		870		1 918		860		1 896	
- on rear wheels	440		970		440		970		440		970	
Maximum weight, laden	1 800		3 968		1 800		3 968		1 760		3 880	
- on front wheels	1 050		2 315		1 050		2 315		1 050		2 315	
- on rear wheels	800		1 763		800		1 763		800		1 763	
Maximum towing weights	630		1 388		630		1 388		630		1 388	
- without overrun brake	1 800		3 968		1 800		3 968		1 800		3 968	
- with continuous brake												

On "Pallas" version, these weights rise by 20 kg (44 lbs).

Dimensions Overall length : 4.87 m (15' 11 7/8")

Overall width : 1.80 m (5' 11") [1.81 m (5' 11 1/4") on "Pallas" model]

Height when empty : 1.47 m (4' 9 3/4")

Turning circle : approx 11 m (36')




Fig. 49 - Overall dimensions

General

	"DS 23"	"D Super 5"	"DS 20", "D Super", "D Special"
Description	Citroën type DX 4	Citroën type DX 2	Citroën type DY 3
Number of cylinders	4 - in line	4 - in line	4 - in line
Bore	93.5 mm	90 mm	86 mm
Stroke	85.5 mm	85.5 mm	85.5 mm
Cubic capacity	2.347 cc	2.175 cc	1.985 cc
Compression ratio	8.75 : 1	8.75 : 1	8.75 : 1
Maximum output (DIN)	115 BHP at 5,500 r.p.m.	106 BHP at 5,500 r.p.m.	99 BHP at 5,500 r.p.m.
Maximum torque (DIN)	18.7 mkg (134 ft lbs) at 3,500 r.p.m.	17 mkg (128 ft lbs) at 3,500 r.p.m.	15.1 mkg (108 ft lbs) at 3,500 r.p.m.

Maximum engine speed: 6 000 r.p.m.

Crankshaft : 5 bearings

Timing

With a theoretical valve clearance of 1.1 mm (engine cold) :

Inlet opens 0° 30' BTDC

Inlet closes 42° 30' ABDC

Exhaust opens 38° 30' BBDC

Exhaust closes 4° 30' ATDC

Side-mounted camshaft, chain driven.

Clearance of rockers when hot :

inlet : 0.20 mm

exhaust : 0.25 mm

Fuel supply

Dry air filter with summer/winter control (if fitted)

Fuel pump, push-rod operated.

Carburettor :

"DS 23"	"D Super 5"	"DS 20"	"D Special", "D Super"
Weber 28 × 36 DMA-4 or Weber 28 × 36 DM-2	Weber 28 × 36 DMA-2	Weber 28 × 36 DM-1	Weber 28 × 36 DMA-3

Manual choke control

Crankcase gas recycling device with oil thrower incorporated in flame trap on crankcase..

Fuel tank capacity : 65 l. (14.3 imp. gallons).

Fuel : Super Premium, 4-star. (97-99 octane).

Lubrication

Lubrication under pressure.

Oil pressure for a temperature of 60° to 65° C (140° - 149° F) :

4-5 bars (57-73 p.s.i.) at 4 000 r.p.m.

[minimum : 0.55 bars (8 p.s.i.) at 1 000 r.p.m.]

Oil capacity :

— Sump capacity = 4.5 l. (8 imp. pints)

— After changing the oil filter cartridge = 5 l. (8.8 imp. pints).

Cooling system

By means of water, radiator, thermostat and fan at the front.

Capacity : 13 l. (23 imp. pints) including heating system on "DS 23"

10.8 l. (19 imp. pints) including heating system on "D Super 5"

10.6 l. (18 imp. pints) including heating system on "DS 20", "D Super" and "D Special"

Ignition

Firing order : 1 - 3 - 4 - 2

Strobe setting : 23° at 2 000 r.p.m. on "DS 23"

20° at 2 000 r.p.m. on "D Super 5"

28° at 2 000 r.p.m. on "DS 20", "D Super" and "D Special"

Sparking plugs : Fitted by the manufacturer : Marchal 35.1 B - AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S

Other authorised types : see page 36

Spark gap : 0,6-0,7 mm (0.024" - 0.028")

Exhaust

Main silencer

Auxiliary silencer

Clutch

Single dry disc.

Hydraulic version : hydraulic control has no pedal and is operated by the gear selector and accelerator.

Manual gear-change version : Mechanical, by means of a pedal.

Gearbox, drive and differential

Compact assembly "en bloc" with the engine.

Hydraulic gear-change version : by means of a selector in front of the steering-wheel ("DS 23", "DS 20").

4 speeds, synchronised and reverse.

Gear ratios :

1st : 0.3076 (3.2 : 1)

2nd : 0.5454 (1.8 : 1)

3rd : 0.8285 (1.2 : 1)

Crownwheel and pinion ratio : 8/35 (4.375 : 1).

4th : 1.1739 (0.85 : 1)

Reverse : 0.3170 (3.1 : 1)

Manual gear-change version by lever under the steering wheel.

5 speeds, synchronised and reverse.

Gear ratios on "DS 23" and "D Super 5" models

1st : 0.3076 (3.2 : 1)

4th : 1.0312 (0.97 : 1)

2nd : 0.5151 (1.9 : 1)

5th : 1.2758 (0.78 : 1)

3rd : 0.7567 (1.3 : 1)

Reverse : 0.3170 (3.1 : 1)

Crownwheel and pinion ratio : 8/35 (4.375 : 1).

4 speeds, synchronised and reverse.

Gear ratios on "D Super" and "D Special" models

1st : 0.3076 (3.2 : 1)

4th : 1.2727 (0.78 : 1)

2nd : 0.5454 (1.8 : 1)

Reverse : 0.3170 (3.1 : 1)

3rd : 0.8823 (1.1 : 1)

Crownwheel and pinion ratio : 7/34 (4.837 : 1).




Fig. 50 - Hydraulic gear-change circuit ("DS 23" and "DS 20")

High pressure pump.

Large capacity reservoir.

Hydropneumatic accumulator with pressure regulator.

Capacity of hydraulic system : 5.2 l. (9.25 imp. pints).

Capacity of main hydropneumatic accumulator : 0.38 l. (0.77 imp. pints).

Maximum operating pressure in accumulator : 175 bars (2 538 p.s.i.)




Fig. 51 - Pressure reserve

Independent wheels at the front and at the rear.

Each wheel is suspended on the chassis, by 2 transverse arms for the front wheels and one trailing arm for the rear wheels.

Stabilising bars at the front and at the rear.

Automatic pressure balancing between the suspension units on the same axle.

Automatic height correctors.

Height adjustment of the vehicle from the driver's seat.




Fig. 52 - Height correction




Fig. 53 - Hydraulic suspension circuit

Main brake

Discs on the front wheels.

Drums on the rear wheels.

Diameter of discs : 300 mm (11.8")

Diameter of drums : 255 mm (10")

Diameter of wheel cylinders :

- Front - two opposed of 60 mm (2.4")
- Rear - one of 18 mm (0.7")

Width of rear brake lining : 35 mm (1.4")

Total surface area of main brake :

447 cm² (69.3"²)

Automatic adjustment for front brake pad wear.

Warning lamp for front brake pad wear.

Split circuit hydraulic operation (L.H.M. mineral fluid).

Constant effectiveness is ensured by pressure supplied from a reserve.

Automatic braking distribution between the axles, automatic limitation on the rear axle, in relation to the amount and the distribution of the load, according to model.

Illuminated warning lamp for low pressure in the supply to the braking circuit.

Parking brake

Separate linings from those of the main brake.

Mechanical action on the front wheel discs.

Control by means of a pedal (locking by a hand lever) or by a hand lever (if fitted).

Total surface area of the parking brake : 95 cm² (14.7"²)

Ratio of lever arms : 1/40.3.





Fig. 54 - Brake control

Manual or hydraulically assisted rack and pinion steering according to model.

Transmission to the wheels by levers and track rods.

Overall ratio : 1/15 (1/20 on manual steering)

Turning circle : approx 11 m (36')

Wheels secured by 5 studs.

Rims of 5.5".

- on "DS 23" and "D Super 5"

French market:

Michelin 180 HR 15 X AS at front

165 HR 15 X AS at rear and on spare wheel

- on "DS 20", "D Super", "D Special"

Michelin 180 HR 15 X AS at front

155 HR 15 X AS at rear and on spare wheel

Other markets:

Michelin 180 HR 380 X AS on all five wheels.

Equal camber on both sides

Caster angle : 1° 30'

Toe in of front wheels: 2 to 4 mm towards the front




Fig. 55 - Hydraulically assisted rack and pinion steering (if fitted)

Electrical equipment

Voltage : 12 V

Alternator

- maximum output : 700 W
- commences to charge at: 1 200/1.77 r.p.m. (approx. 675 engine r.p.m.)

Battery

- capacity : 200/40, 250/50 or 300/60 AH CEI (according to model)
- negative earth

Starter motor

- output : approx. 1 kW
- drive by solenoid and free wheel drive.

Conventional type distributor.

10 fuses (3 of 16 amps, 7 of 10 amps)

4 Quartz Iodine headlamps grouped in two units.

2 reversing lamps. (if fitted)

Self-levelling headlamps.

Directional Long-range headlamps. (if fitted).

2-speed windscreen wiper motor.

Electric windscreen washer.

Blower for forced air system.

Headlamp flashers and horns, including compressor horn (on certain models).

Electronic tachometer.

Electric clock (if fitted).

Electric rear window heater (if fitted)

Cigarette lighter.

11 warning lamps.

Radio set with sound mixer (if fitted)

Accessory terminal (behind dashboard) : 10 amps maximum.

Interior lighting :

- Rear boot, interior lighting, dashboard.
- Heater control, glove compartment, ashtray, cigarette lighter, ignition key (if fitted).




Fig. 56 - Figure showing ignition wiring

Bulb table (according to model)

Dipped/Main beam headlamps (large diameter) European Dip- type bulbs	: 12 V - 45/40 W P 45 - T 41 type	Reversing lamps	: 12 V - 21 W - P 25/1 type
Dipped/Main beam headlamps (large diameter) Q.I. bulbs	: 12 V - 55/60 W H 4 or H 1 type	Numberplate lighting	: 12 V - 5 W - R 19/5 type
Long range headlamps (small diameter)		Interior lamps :	: 12 V - 7 W - 38 mm long Festoon
European Dip type bulbs	: 12 V - 45/40 W - P 45 - T 41 type	interior lamps : "Pallas"	: 12 V - 15 W bayonet
Q.I. bulbs	: 12 V - 55/60 W - H 1 type	Glove compartment	: 12 V - 2 W - T 8/2 type
Side-lamps	: 12 V - 4 W - T 8/4 type	Rear boot :	: 12 V - 7 W - 38 mm long Festoon
Tail lamps	: 12 V - 5 W - R 19/5 type	Dashboard lighting	: 12 V - 3 W - Wedge type base tube $\varnothing = 10$
Direction indicators : front	: 12 V - 21 W - P 25/1 type	Warning lamps	: BA 9S - 12 V - 2 W - T 8/2 type
rear	: 12 V - 21 W - P 25/1 type	Clock lighting	: BA 9S - 12 V - 2 W - T 8/2 type
Brake lamps	: 12 V - 21 W - P 25/1 type	Heating control lighting	: BA 9S - 12 V - 2 W - T 8/2 type
		Ashtray lighting	: BA 9S - 12 V - 2 W - T 8/2 type
		Lighting for cigarette lighter	: BA 9S - 12 V - 2 W - T 8/2 type




Fig. 57 - Exterior lighting and signals

- 1 - Long range headlamps
- 2 - Dipped/Main beam headlamps
(with front side-lamps)
- 3 - Front direction indicators

- 4 - Rear direction indicators
- 5 - Brake-lamps
- 6 - Tail lamps
- 7 - Numberplate lamps
- 8 - Reversing lamps

5 - seater saloon.

Mono-shell body.

Total area of glass : 2.25 m² (27.2 sq ft).

Locks which may be operated from the inside.

Separate front seats, adjustable in length and angle of backrest.

Seat adjustable in height and angle (if fitted)

Headrest adjustable (if fitted)

Centre front arm rest (if fitted)

Rear bench seat with retractable centre armrest.

Anchorage for seat belts.

Interior day/night and exterior side rear-view mirrors.

Ventilation by means of forced air system.

Thermostatically controlled heating.

Boot lid held in the 'open' position by means of automatic telescopic stays.

Volume of rear boot : 500 dm³ (17.7 cu ft).

MISCELLANEOUS INFORMATION

Running in, servicing, guarantee..	56
Driving and running costs	56
Towing a trailer	57
Vehicle identification	57
Replacement Parts	57
Travelling abroad	58

Your attention is drawn particularly to the sections entitled "Running in" and "Servicing and Guarantee".
If you are travelling abroad, the translations into 4 languages of the recommended supplies for your car will be of use to you at Service-Stations.

Running-in

During the first 600 miles (1 000 km), do not exceed 4 000 engine r.p.m. Avoid over-accelerating for the first 1 200 miles (2 000 km), after which, there is no restriction.

Avoid also during this period :

- harsh acceleration,
- fierce braking (the brake linings must be run in),
- long distances at constant speed,
- labouring the engine at too low speeds.

Servicing and guarantee

At the time of delivery you will be given a Maintenance Booklet and your "Guarantee Card" with a 600 miles (1 000 km) "Servicing Certificate".

After the first 600 miles, any Citroën Dealer, whether or not he supplied the vehicle, will service the car free of charge, on producing the Servicing Certificate.

Only the cost of the materials used will be charged for.

The Dealer will keep the Servicing Certificate and sign the Guarantee Card.

This is necessary for you to benefit from the Guarantee.

Influence of driving techniques on running costs.

The manner in which a car is driven affects its running costs, particularly as far as fuel, oil and tyre expenses are concerned.

Running costs increase with :

- speed,
- frequent and prolonged use of low gears,
- accelerating and braking too often or too fiercely,
- unnecessary use of the accelerator pedal,
- misuse of the choke ,
- taking bends at high speeds,
- tyres inflated to incorrect pressures.

The oil consumption, which varies with the use of the car, is also influenced when running in the engine. You are advised to pay particular attention to this and also to the oil change section in the Maintenance Guide.

Towing a trailer

If you wish to use a caravan or trailer, first consult your Citroën Dealer who will give you all the necessary advice, especially in so far as the legal requirements are concerned

The maximum towing weights in France are :

- trailer without overrun brake : 630 kg. (1 389 lbs.)
- trailer with overrun brake : 1 250 kg (2 756 lbs.)
- trailer with continuous brake : 1 800 kg. (3 967 lbs.)

* We particularly draw your attention to the fact that above 3,307 lbs. (1.500 kg), you must be able to control the brakes of the trailer from the driver's seat, even if the transmission on the braking system of the towing vehicle (to the trailer) fails.

Consult your Dealer about local legal requirements.

Identification

Positions

Manufacturer's plate : under the bonnet, on the scuttle, R.H. side.

Stamped mark : on the upper part of the scuttle, R.H. side.

Engine plate : on the engine housing, R.H. side.

Information

On manufacturer's plate :

- type of vehicle
- series
- chassis number
- Gross Vehicle Weight : (P.T.C.) (in kg)
- Gross Train Weight : (with trailer) (P.T.R.) (in kg)

On stamped mark :

- type of vehicle
- series
- chassis number

Engine plate :

- make
- engine type
- manufacturer's number

In France, the type of vehicle and the chassis number are also indicated on the "Grey Card" (registration document).

Replacement parts

Original parts are sold only in the Citroën network.

It is in your interest, for your safety and your guarantee, to refuse any other part.

Indicate on the order :

- series,
- chassis number,
- type of vehicle.
- type and number of the engine.

The Replacement Parts catalogue and the Repair Manual are sold by Dealers and Concessionaires.




Fig. 58 - Manufacturer's plate



Fig. 59 - Engine plate

MERKBLATT FÜR PFLEGE- UND WARTUNGS-DIENST**Reifen** : MICHELIN 185 HR 15 X ASDruck = 2 atü vorn
1,8 atü hinten
2,2 atü für Ersatzrad**Kraftstoff** : SuperFassungsvermögen des Kraftstoffbehälters
= 65 l**Motoröl** : ÖL TOTAL Altigrade GT 20 W 40 oder GTS
20 W 50

In sehr kalten Ländern :

ÖL TOTAL Altigrade GT oder GTS 10 W 30
Fassungsvermögen des Motors = 4,5 l
nach Austausch der Oelfilterpatrone 5 l**Hydraulische Anlage** : Grüne Flüssigkeit « LHM » TOTAL
Fassungsvermögen des Hydraulikbehälters
= 5,2 l**Kühler** : Wasser und Frostschutzmittel TOTAL :"DS 23" = 6 l bei 7 l Wasser - "D Super 5"
= 3,8 l bei 7 l - "DS 20" - "D Super" =
3,6 l bei 7 lFassungsvermögen : "DS 23" = 13 l "D Super 5"
= 10,8 l - "DS 20", "D Super" = 10,6 l**Scheibenwascher** : Wasser, dem man :— zu jeder Jahreszeit ein Produkt wie z.B.
"Stop-Clair"
— im Winter ein Produkt wie z.B. "Stop-
Gel" zusetzen kann**Batterie** : 12 V-200/40, 250/50 oder 300/60 AH CEI
Destilliertes Wasser (keine Säure) zufüllen**Zündkerzen** : AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S
Marchal 35.1 BSiehe weitere Möglichkeiten auf Seite 36
Elektrodenabstand = 0,6-0,7 mm**Glühbirnen** : Siehe Tabelle auf Seite 53**MEMENTO POUR LA STATION-SERVICE (à l'étranger v. p. 58-59)****Pneumatiques** : Michelin 185 HR. 15 X ASPression = 2 bars à l'avant
1,8 bar à l'arrière
2,2 bars à la roue de secours**Carburant** : Super - Capacité = 65 litres**Huile moteur** : Huile TOTAL "GT20W 40" ou "GTS20W 50"

Dans pays très froid :

TOTAL "GT 10 W 30" ou "GTS 10 W 30"

Capacité carter moteur : 4,5 l

après échange cartouche filtre à huile: 5 l

Huile boîte de vitesses : Huile "TOTAL Extrême pression SAE 80"Capacité boîte 4 vitesses : 2 l - boîte 5 vi-
tesses : 2,5 l**Graissage général** : "TOTAL multis"**Installation** : Liquide vert TOTAL "LHM"**hydraulique** : Capacité = 5,2 l**Radiateur** : Eau et antigel "TOTAL"

Capacité = 13 l sur "DS 23"

10,8 l sur "D Super 5"

10,6 l sur "DS 20" - "D Super"

Lave-glace : Eau à laquelle il peut être ajouté :— en toute saison : un produit genre "Stop-
Clair"

— en hiver : un produit genre "Stop-Gel"

Batterie : 12 V - 200/40, 250/50 ou 300/60 AH CEI

Eau distillée (ne pas ajouter d'acide)

Bougies : AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S
Marchal 35.1 B

Autres montes autorisées : voir page 36

Ecartement des électrodes = 0,6 à 0,7 mm

Lampes : Voir tableau page 53**Dot not forget to ask your insurance company for an International Green Card.****This will avoid extra expenses when entering countries where insurance is compulsory and can avoid serious complications in the event of an accident in another country.****However, it is only valid in those countries which are covered by the insurance policy (refer to the geographical limits in the "General**

PROMEMORIA PER LA STAZIONE DI SERVIZIO

Pneumatici : MICHELIN 185 HR 15 X AS
Pressioni = 2 kg/cm² per le ruote anteriori
1,8 kg/cm² per le ruote posteriori
2,2 kg/cm² per la ruota di scorta

Carburante : Super
Capacità = 65 litri

Olio motore : TOTAL Altigrade GT 20 W 40 o GTS 20 W 50
Capacità = 4,5 litri
Dopo sostituzione cartuccia 5 litri

Impianto idraulico : Liquido verde « LHM » TOTAL
Capacità = 5,2 litri

Radiatore : Acqua con anticongelante TOTAL : 6 litri per
7 l acqua "DS 23"; 3,8 litri per 7 l "D Super"
5" 3,6 litri per 7 l "DS 20" - "D Super"
Capacità = 13 litri "DS 23"
10,8 litri "D Super 5"
10,6 litri "DS 20" - "D Super"

Lava cristallo : Acqua alla quale è possibile aggiungere :
— in ogni stagione : un prodotto tipo "Stop-Clair"
— in inverno : un prodotto tipo "Stop-Gel"

Batteria : 12 V 200/40, 250/50 o 300/60 AH CEI
Acqua distillata (non aggiungere acido)

Candele : AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S
Marchal 35.1 B
Per le altre marche possibili vedere P. 36
Distanza degli elettrodi = 0,6 à 0,7 mm

Lampade : Ved. tabella pag. 53

MEMENTO PARA LA ESTACION SERVICIO

Neumáticos : MICHELIN 185 HR 15 X AS
Presión = 2 kg/cm² bars delantero
1,8 kg/cm² trasero
2,2 kg/cm² rueda de auxilio

Combustible : Super
Capacidad = 65 litros

Aceite motor : TOTAL Altigrade GT 20 W 40 o GTS 20 W 50
Capacidad = 4,5 litros
Después del cambio del cartucho 5 litros

Circuito hidraulico : Liquido verde « LHM » TOTAL
Capacidad = 5,2 litros

Radiator : Agua con anti-hielo TOTAL : 6 litros por 7 l
agua "DS 23"; 3,8 litros por 7 l "D Super 5"
3,6 litros por 7 l "DS 20" - "D Super"
Capacidad = 13 litros "DS 23"
10,8 litros "D Super 5"
10,6 litros "DS 20" - "D Super"

Lava parabrisa : Agua en la cual se puede agregar :
— en todos tiempos : un producto del tipo
"Stop-Clair"
— en invierno : un producto del tipo "Stop-Gel"

Bateria : 12 V 200/40, 250/50 o 300/60 AH CEI
Agua distilada (nunca agregar ácido)

Bujias : AC 42 FS - Bosch W 225 T 35 - Eyquem 705 S
Marchal 35.1 B
Ver otras marcas posibles pagina 36
Abertura de los electrodos = 0,6 à 0,7 mm

Lámparas : Ver tablero pagina 53

If you are going to a country where the opposite rule of the road applies, first consult your Citroën Dealer beforehand for correct setting of the dipped headlamps.
In certain countries, a large sum may be required as deposit in case of an accident causing personal injury. There are insurance policies

- A** Accumulator (see battery)
 Air-conditioning 16
 Anti-theft device 10
 Ashtrays 18
 Auxiliary clutch 10
- B** Battery, levels 20
 Battery, maintenance 23
 Battery, replacement 36
 Body, data 54
 Body, maintenance 24
 Bonnet 3
 Boot 2
 Brakes 12-48
 Brakes, lining wear 2-13
 Bulbs, changing 30
 Bulbs, table 53
- C** Capacities on back of handbook
 Changing the battery 36
 Changing a bulb 30
 Changing a fuse 35
 Changing a sparking plug 28
 Changing a wheel 28
 Charging indicator 6
 Chassis No 57
 Chassis No stamping 57
 Choke 10
 Cigarette lighter 18
 Clock, electric 6
 Clutch 44
- D** Dashboard 6
 Defrosting 23
 Demisting 16
- Dimensions, main 40
 Direction indicators 14-33
 Doors, opening 2
 Driving position 8
- E** Electrical diagram 52
 Electrical system 52
 Engine data 42
 Engine, number plate 57
 Engine, oil level 20
 Engine, oil, warning lamp 6
- F** Fuel, topping up 3
 Fuel gauge 6
 Fuse boxes 35
 Fuses 35
- G** Gearbox 44
 Gear changing 12
 Gearlever 12
 Glove compartment 2
 Ground clearance, setting 12
 Guarantee 56
- H** Headlamps, adjustment 34
 Headlamps, controls 14
 Headlamps, flashing 14-33
 Headrest 8
 Heating 8
 Height correction 12a
 Horns 14
 Hydraulic system, draining 20
 Hydraulic system, LHM fluid 20
 Hydraulic system, general 45
 Hydraulic system, pressure-
 warning lamp 6
- I** Identification of car 57
 Ignition lock 10
 Interior fittings 54
 Interior lamp 18-33
 Instruments 6
- K** Keys 2
- L** Levels, check and top-up 20
 Lighting, exterior 15-30
 Lighting, interior 18
 Locks 2
- M** Mileage recorders 6
 Minor repairs 27
 Maintenance 19
- P** Pre-starts checks on back of handbook
 Polishing 25
- R** Radiator, filling 20
 Radiator, maintenance 23
 Rear-view mirror 9
 Rear-window, heating 17
 Rear-window, cleaning 26
 Replacement parts, orders 57
 Running-costs 56
- S** Seat belts 9-26
 Seats 8
 Seats, backrest adjustment 8
 Service at 600-miles 56
 Signalling 14
 Sparking plugs and gaps 36
 Speedometer 6
 Spots on upholstery 26

Starting engine	10	U Upholstery, cleaning	26
Stopping distances	13	V Ventilation	16
Stopping the engine	10	W Warning lamps	6
Sun-visors	18	Washing the car	24
Suspension	46	Water, battery, windscreen washers	20
T Tachometer, electronic	6	Wear, brake linings	2-13
Tar, removal	25	Weights	40
Technical Data	39	Wheel, changing and brace	28
Temperature, interior	17	Wheels, changing round	22
Temperature, engine oil, warning lamp	6	Windscreen washer, control	14
Towing the car	38	Windscreen washer, filling	20
Towing a trailer	57	Windscreen wipers	14
Transmission	44	Windows, cleaning	24
Transparent plastic covers, cleaning	24	Winkers	14-33
Travelling abroad	58	Wiring diagram	52
Tyre pressures	22		
Tyres	22		

The descriptions and diagrams shown are illustrative only.

The Société Citroën reserves the right to modify its models without necessarily keeping this manual up to date.

REMINDER FOR SERVICE-STATION (for foreign countries, see pages 58 and 59)DS-FE
DS 20 HYDR.DS - FE
DS 21 M MANUAL
DS - FD

- Tyres :** Michelin
180 HR 15 X AS
Pressure = 29 p.s.i. at front, 29 p.s.i. at rear, 32 p.s.i. on spare wheel
- Fuel :** Super - Capacity = 14.5 imp gallons
- Engine oil :** TOTAL "GT 20 W 40" or "GTS 20 W 50" oil
In very cold countries :
TOTAL "GT 10 W 30" or "GTS 10 W 30"
Capacity : 8 imp pints
After filter change : 8.8 imp pints
- Gearbox oil :** "TOTAL Extreme pressure SAE 80" oil
4 - speed gearbox capacity : 3.5 imp pints - 5 - speed gearbox : 3.9 imp pints
- Lubrication :** "TOTAL" multis
- Hydraulic system :** Green "TOTAL" L.H.M. fluid
Capacity = 9 imp pints
- Radiator :** Water and "TOTAL" anti-freeze
Capacity = 21 imp pints on "DS 23"
19 imp pints on "D Super 5"
18 imp pints on "DS 20" and "D Super"
- Windscreen washer :** Water to which may be added
— in any season: a product like "Stop-Clair", Clearalex, Screen-clear, etc...
— in winter : a product like "Stop-Gel", Clearalex, Screen-clear, etc...
- Battery :** 12 V - 200/40, 250/50 or 300/60 AH CEI (according to model)
Distilled water (do not add acid)
- Sparking plugs :** AC 42 FS - BOSCH W 225 T 35 - EYQUEM 705 S - MARCHAL 35.1 B
Other authorized fittings on page 36
Spark gap : 0.024" to 0.028"
- Bulbs :** See table on page 53

PRE-START CHECKS

Levels : Fuel
(p. 20) Engine oil
Radiator
"LHM" fluid
Battery
Windscreen washer

Operation : Warning lamps
Horns
Headlamp control
Headlamps
Direction indicators
Brake lamps

Miscellaneous : Rear-view mirror setting
Tyre pressures
Ground clearance adjustment